## project

May 4, 2019

## 1 36610 - Python and Unix for Bioinformaticians

- 1.1 Project 6: Resistance to antibiotics
- 1.2 May 4, 2019
- 1.2.1 Peter's discussion
  - res genes can look alike/similar
  - he uses .find()
  - check only part of the read, if suffienctly enough kmers match, then go through each kmer of that read
  - do NOT loop over the res gene dict (-> slow)

## Set of RES kmer's to quickly check if sequencing read needs further investigation

```
In [ ]: # Pseudocode
        # for line in resistance_genes_file:
             get header and sequence and store in a list
             generate a set of kmers and a dictionary of kmer and a value of O
        # for line in sequencing_read_1 and 2:
              isolate read sequence
              check if at least 2 out 3 read kmers match the resistance gene set
              if so:
                  for each kmer in the read sequence:
                      if kmer in resistance gene dictionary:
        #
                          increase its value by 1
        #
              else:
        #
                  check if the reverse complement has at least 2 out of 3 matches
                  if that is the case:
                      generate kmers for the reverse complement, and increase matching ones by
              otherwise discard this read (and do not generate kmers for it step by step)
        # for resistance_gene in list_of_resistance_gene_header_and_sequence:
              get the header
              get the sequence
```

```
get the length of the sequence
              for each kmer in that sequence:
        #
                  add the depth of each kmer to a temporary list
                  check if that addition would result in a coverage <95%
                  if it passes:
                      continue collecting kmer depths for that sequence
                      discard this sequence
              since >95% coverage, and check for >=10 depth:
                  we have a winner: store gene name, coverage and minimum depth in a final lis
        # sort the list according to coverage and depth, and print it.
In [17]: # Libraries
         import gzip # Provides support for *.gzip files
         import time # Used for runtime measurement
         time_start = time.time() # start timer
         # User defined kmer length
         kmer_length = 19
         # Functions
         def reverse_complement(DNA_sequence):
             """Reverse complement a given DNA sequence"""
             DNA translation table = str.maketrans("ACGT", "TGCA")
             rev_compliment = DNA_sequence.translate(DNA_translation_table)
             return rev_compliment[::-1]
         def read_in_seq_reads(read, kmer_length):
             """Go through sequencing reads and check if at least 2 out of 3 kmer match
             the resistance gene kmer set. If so, generate all kmers for that read and
             increase the count for matching kmers. Also consider the reverse complement."""
             raw_reads = gzip.open("data/Unknown3_raw_" + read + ".txt.gz", "rt")
             # Variables
             read seq = ""
             rev_read_seq = ""
             read kmer = ""
             line\_count = 3
             for read_line in raw_reads:
                 if (line count % 4 == 0):
                     read_seq = read_line.rstrip() # arrived at read sequence
                     # Generate 3 read kmers and check if at least 2 match to the
                     # resistance gene dictionary. If so, generate all kmers for
                     # that read, otherwise try the reverse complement. If the
                     # reverse complement does not have at least 2 matches, ignore
```

```
read_kmer_set = set()
            read_kmer_set.add(read_seq[1:1+kmer_length])
            read_kmer_set.add(read_seq[41:41+kmer_length])
            read_kmer_set.add(read_seq[81:81+kmer_length])
            if len(read_kmer_set.intersection(ResKmerSet)) >= 2:
                for j in range(0, len(read_seq), 1):
                    if (j < len(read_seq) - kmer_length + 1):</pre>
                        read_kmer = read_seq[j:j+kmer_length]
                        if read_kmer in ResKmerDict.keys():
                            ResKmerDict[read_kmer] += 1
            else:
                rev_read_seq = reverse_complement(read_seq) # reverse complement
                read_kmer_set = set()
                read_kmer_set.add(rev_read_seq[1:1+kmer_length])
                read_kmer_set.add(rev_read_seq[41:41+kmer_length])
                read_kmer_set.add(rev_read_seq[81:81+kmer_length])
                if len(read_kmer_set.intersection(ResKmerSet)) >= 2:
                    for j in range(0, len(rev_read_seq), 1):
                        if (j < len(rev_read_seq) - kmer_length + 1):</pre>
                            read_kmer = rev_read_seq[j:j+kmer_length]
                            if read_kmer in ResKmerDict.keys():
                                ResKmerDict[read_kmer] += 1
        line_count += 1
    raw_reads.close()
print("Processing resistance genes...")
                      # Will contain resistance gene sequence temporarily
fasta = []
store_fasta_seqs = [] # List of header and sequence of resistance file
ResKmerSet = set() # Resistance genes kmer set
ResKmerDict = dict() # Unique resistance genes kmer dictionary {kmer1:0, kmer2:0, ...
ResFile = open("data/resistance genes.fsa", "r")
for line in ResFile:
    line = line.rstrip()
    if line.startswith(">"):
        if fasta:
            full_seq = "".join(fasta) # Store entire resistance gene sequence
            store_fasta_seqs.append(header)
            store_fasta_seqs.append(full_seq)
            # Generate kmers of the resistance gene,
            # add them to a kmer set, and
            # add them to a kmer dictionary with value O
            for i in range(0, len(full_seq), 1):
```


# this read.

```
kmer = full_seq[i:i+kmer_length]
                if (i < len(full_seq) - kmer_length + 1):</pre>
                    ResKmerSet.add(kmer)
                if kmer not in ResKmerDict.keys():
                    ResKmerDict[kmer] = 0
            fasta = []
        header = line
    else:
        sequence = line
        fasta.append(sequence)
# Process last resistance gene
if fasta:
    full_seq = "".join(fasta) # Store entire resistance gene sequence
    store_fasta_seqs.append(header)
    store_fasta_seqs.append(full_seq)
    # Generate kmers of the resistance gene,
    # add them to a kmer set, and
    # add them to a kmer dictionary with value O
    for i in range(0, len(full_seq), 1):
        kmer = full_seq[i:i+kmer_length]
        if (i < len(full_seq) - kmer_length + 1):</pre>
            ResKmerSet.add(kmer)
        if kmer not in ResKmerDict.keys():
            ResKmerDict[kmer] = 0
ResFile.close()
print("Finished processing resistance gene file.")
print("Processing read file 1...")
read_in_seq_reads("reads_1", kmer_length)
print("Processing read file 2...")
read_in_seq_reads("reads_2", kmer_length)
print("Filtering resistance genes that do not match the requirements (>95% coverage,
skip_sequence = True
counter = 0
sequence = ""
final_result = list()
from matplotlib import pyplot as plt
import numpy as np
for i in range(len(store_fasta_seqs)):
    if (counter % 2 == 0):
        # arrived at gene id
```


```
header = store_fasta_seqs[i]
             else:
                 # arrived at gene sequence
                 temp = list()
                 sequence = store_fasta_seqs[i]
                 len_of_sequence = len(sequence)
                 # Generate kmers of the sequence.
                 # Add the depth to a kmer depth list, and check for coverage.
                 # As soon as the coverage drops below 95%, ignore the sequence.
                 # (= does not fulfill the requirements).
                 for j in range(0, len(sequence), 1):
                     if (j < len(sequence) - kmer_length + 1):</pre>
                         read_kmer = sequence[j:j+kmer_length]
                         depth_of_kmer = ResKmerDict[read_kmer]
                         temp.append(depth_of_kmer)
                         temp_coverage = 1 - temp.count(0) / len_of_sequence
                         if (temp_coverage < 0.95): # check coverage, stop once below 95%
                             skip_sequence = False
                             break
                 # Once we processed every kmer of the sequence and the coverage
                 # is still >95\%, we check for minimum depth (>=10)
                 if skip_sequence and (min(temp) >= 10):
                     x = np.linspace(0, len(temp), len(temp))
                     plt.plot(x, temp)
                     plt.ylim(0, max(temp))
                     plt.title(header)
                     plt.show()
                     #print(temp)
                     final_result.append([header, temp_coverage, min(temp)])
             counter += 1
         # Sort results according to coverage and then minimum depth. Print results.
         final_result.sort(key=lambda x: (x[1], x[2]), reverse=True)
         print("Coverage [%]\tMinimum depth\tGene")
         for i in range(len(final_result)):
             print("\{:.2f\\t\t\{:d\\t\t\\}\".format(final_result[i][1] * 100, final_result[i][2],
         time_end = time.time()
         time_elapsed = time_end - time_start
         time_elapsed
Processing resistance genes...
Finished processing resistance gene file.
Processing read file 1...
Processing read file 2...
Filtering resistance genes that do not match the requirements (>95% coverage, >=10 depth)...
```

skip\_sequence = True


>aac(6')Ib-cr\_1\_DQ303918 Fluoroquinolone and aminoglycoside resistance:




>strA\_4\_AF321551 Aminoglycoside resistance:Alternate name; aph(3")-Ib





>strB\_1\_M96392 Aminoglycoside resistance:Alternate name; aph(6)-Id







>blaCTX-M-15\_23\_DQ302097 Beta-lactam resistance:Alternate name; UOE-1









>blaTEM-1B\_1\_F910132 Beta-lactam resistance:Alternate name; RblaTEM-1
50 - 40 - 30 - 20 - 400 600 800







Coverage [%]	Minimum depth	Gene
100.00	27	>blaSHV-28_1_HM751101 Beta-lactam resistance:
100.00	24	>strA_4_AF321551 Aminoglycoside resistance:Alternate na
100.00	21	>strB_1_M96392 Aminoglycoside resistance:Alternate name
100.00	20	>blaCTX-M-15_23_DQ302097 Beta-lactam resistance:Alterna
100.00	19	>catB4_1_EU935739 Phenicol resistance:
100.00	18	<pre>&gt;aac(3)-IIa_1_CP023555.1 Aminoglycoside resistance:</pre>
100.00	16	>blaTEM-1B_1_JF910132 Beta-lactam resistance:Alternate
100.00	16	>sul2_2_GQ421466 Sulphonamide resistance:
100.00	15	<pre>&gt;tet(A)_4_AJ517790 Tetracycline resistance:</pre>
100.00	14	>aac(6')Ib-cr_1_DQ303918 Fluoroquinolone and aminoglyco
100.00	14	<pre>&gt;blaOXA-1_1_J02967 Beta-lactam resistance:</pre>

Out[17]: 54.684276819229126